



## Ask about our 5 Year/100,000 mile powertrain protection

### What is covered by this vehicle service contract\*?



**Engine group:** All internally lubricated parts. Crankshaft and bearings, oil pump, fuel pump, diesel injection pump, internal timing gears or chain/belt, camshaft, camshaft bearings, valve lifters, rocker arm assemblies and push rods, valve guides, pistons and rings, wrist pins, connecting rods, exhaust manifold, motor mounts, distributor drive gear and water pump. The engine block and cylinder heads are covered only if damage is caused by the failure of an internally lubricated part. **Rotary engine:** All of the above listed parts plus rotors, rotor seals, rotor chamber, eccentric shaft and bearings.



**Transmission, transaxle and transfer case (4x4/AWD):** All internally lubricated parts. Drive shaft/U joint, torque converter, and transmission mounts. Case housings are covered only if damaged by the failure of an internally lubricated part.



**Drive axle group (front or rear):** Drive axle housing including pinion bearings, side carrier bearings, ring and pinion gears, carrier assembly, thrust washers, axles, axle bearings, constant velocity joints, internal transaxle seal, and drive axle housing only if damaged by the failure of an internally lubricated part.



**Seals and gaskets:** Seals and gaskets are covered when replaced in conjunction with a covered failure.



Protect yourself from the cost of unexpected repairs



## Roadside assistance



### Towing

If your covered vehicle breaks down, we'll arrange to have your vehicle towed to the nearest qualified repair facility within a 150-mile radius. This service is available 24/7.



### Flat Tire Change

We'll send a qualified professional to put a spare on your covered vehicle. If your spare isn't functional, we'll provide you with transportation to the nearest tire store for repairs.



### Emergency Fuel Delivery Service

We'll arrange for a service provider to deliver two (2) gallons of fuel to your covered vehicle. You are responsible for the cost of the fuel at the time of delivery.



### Battery Jump Service

If your covered vehicle won't start, we'll arrange for a service provider to assist you with a boost or battery jump.



### Key Lockout Service

If your keys are lost, broken, or locked inside your covered vehicle, we'll send a service provider and pay up to \$100 per occurrence to cover the cost of the locksmith service, excluding the cost of replacement keys. You are responsible for replacement keys.

## Rental car



We will reimburse you for a rental car up to \$30 per 24 hour period, with a \$150 max per claim. In order to qualify the vehicle must: 1) be retained by the repair facility overnight, and 2) have a failure to a covered component based on the coverage plan selected, that if driven, would result in further damage to the vehicle.

**Powertrain coverage begins ninety (90) days and one-thousand (1000) miles after the contract purchase date. A \$100 deductible applies to each repair.**

P.O. Box 830029, Birmingham, AL 35283-0029    800-826-3207    Roadside Assistance: 888-810-5150

**In Florida, the obligor for this Contract is The Advantage Warranty Company, (Florida Certificate of Authority #60071). In Oklahoma, the obligor for this Contract is Interstate Administrative Services, Inc. in New York, the obligor is Western Diversified Services, Inc. In all other states, the obligor is Protective Administrative Services, Inc. (California Provider License Number 0B71048). The contact information for the obligor in all states, except California, is P.O. Box 830029, Birmingham, AL 35283-0029, 1-800-826-3207. In California the contact information for the obligor is P.O. Box 830633, Birmingham, AL 35283-0633, 1-800-826-3207.**

\*Coverage is subject to deductibles, limits and exclusions. The contract covers repairs only of covered parts and only when they suffer a mechanical breakdown as defined in the contract. Under some circumstances, a mechanical breakdown of a covered part may not be covered. Examples include if the failure is due to misuse, lack of proper maintenance or when a non-covered part is what caused the covered part to fail. Also, the exclusions contain a list of parts not covered, some of which may be associated with or contained in component groups that are covered. Examples include the walls, brake drums and rotors, fuses, head and tail light assemblies, hoses, spark plugs and wires. Please see vehicle service contract for details.

Shop online at [cruiseamerica.com](http://cruiseamerica.com)

AUL-CAM-DB (11/23)